

Proper Wiper Folding & Surface Cleaning

A guide to properly fold and use a low-linting presaturated wiper for maximum efficiency and effectiveness in a controlled environment.



1 Withdraw a presaturated wiper from the package. Reseal the container to avoid evaporation.



2 Hold the wiper in mid-air. Take the wiper by its edges and fold in half. The wiper should not be placed on any surface during the folding action.



3 Fold the wiper in half again, creating four cleaning faces: two outside and two inside.



4 Work from the cleanest areas to the dirtiest areas in long, overlapping unidirectional strokes. Each face of the wiper will be used for one straight stroke. Turn the wiper over and make a second stroke.



5 Refold the wiper as shown in Step 2 to enclose the two contaminated faces and expose the two clean faces. Repeat Step 3 using the two clean faces.



6 Wiper may be completely unfolded, reversed, and refolded beginning again at Step 1 to enclose the four contaminated faces and expose the four remaining clean faces.



- Withdraw a presaturated wiper from the package
- Fold the wiper into a square
- 4 clean sides are available to wipe the surface.
- Wipe the surface using the same technique as above
- Always wipe using overlapping strokes
- Never wipe in a circular motion



**CONTAMINATION
CONTROL PRODUCTS**
FOR CLEANROOMS AND CONTROLLED ENVIRONMENTS